



+



INSTRUCTION MANUAL

## Standard Package

1. GPS Unit



2. Mini USB Cable



## Features

1. Multifunction button
2. Mini USB port
3. Battery status LED (Red/Green)
4. GPS status LED (Orange)
5. Log status LED (Green)



DETAILED INSTRUCTIONS AT:  
[SUPPORT.GAMETRAKA.COM](http://SUPPORT.GAMETRAKA.COM)

## Hardware Functions

Hardware Function	Description
<b>USB Port</b>	For charging and data transfer
<b>Multifunction Button</b> Power On	Press & Hold power button for 5 sec to turn on .
<b>Multifunction Button</b> Power Off	Press & Hold power button for 5 sec to turn off .



DETAILED INSTRUCTIONS AT:  
[SUPPORT.GAMETRAKA.COM](http://SUPPORT.GAMETRAKA.COM)

## LED Indicators

Status	Flash	ON	OFF
<b>Power</b> Red/Green	100% charged (green): 1 long flash / 4 seconds  Low (Red): 1 flash / 1 second	Recharging (Green)	Device off
<b>GPS</b> Orange	GPS location established (fixed)	Acquiring GPS location.	
<b>Log</b> Green	5Hz Log Mode: 1 flash / 1 second POI recorded: 3 flashes / 1 second	Memory full	Not logging



DETAILED INSTRUCTIONS AT:  
[SUPPORT.GAMETRAKA.COM](http://SUPPORT.GAMETRAKA.COM)

## Charging your battery

- Please charge fully before first use.
- To charge, connect the device to a compliant USB port via the cable supplied.
- Typical charge time for this unit is 45 minutes.
- A full charge will typically provide 6 hours of logging.
- Do not leave battery in depleted state for extended periods of time as battery damage may occur.
- When not in use disconnect the unit from the charger to prevent battery drain.

## Tips

- For best performance use your SPT in a location with a clear view of the sky. Avoid use around large obstacles e.g. trees or tall buildings.
- **This device is not waterproof and should be protected from moisture.**



DETAILED INSTRUCTIONS AT:  
[SUPPORT.GAMETRAKA.COM](https://support.gametraka.com)

## Warning

- Always charge your SPT within an ambient temp of 0-40 degrees Celsius.
- Do not expose device to strong sunlight or direct heat.
- Do not dispose of this device in fire.
- Do not open or modify your SPT. Doing so will void all warranties.
- This device is not warranted against physical damage or moisture ingress.



DETAILED INSTRUCTIONS AT:  
[SUPPORT.GAMETRAKA.COM](https://support.gametruka.com)